

Pokini

Pokini Tab FS5



Manual

English


Button Layout and Interface description



1. **Power button**: Press to start or close the screen display. You can use this button to put the rugged phone into sleep mode, or wake up from sleep mode.
2. **Scan key**: Open the scan shortcut key.
3. **Barcode Scanner**: Support one-dimensional code/two-dimensional code scanning.
4. **Volume keys**: Decrease/increase volume.
5. **Camera**: 13MP, support photo and video.
6. **Receiver**: Listen to the other party's voice when making a call.
7. **Flash Lamp**: Adjust the brightness of the light when taking pictures.
8. **Audio jack**: This jack can output the audio signal of the rugged mobile phone to the amplifier or earphone.
9. **Type C**: You can exchange data through the data cable, and you can also charge the rugged mobile phone
10. **Pogo pin**: Used to connect the charging base, expand USB and the network port/charging interface


Device initialized setting

Initial desktop: slide the arrow up and go to the desktop, as below picture.




Desktop layout

Desktop Menu introduction: This interface can start the application in a quick way, enter the menu operation, users can add shortcuts to the desktop according to their own needs, as below picture.





Menu bar layout: All the application and user installation applications are here, and all applications can be opened , as below picture.




System settings

Setting: Users can set related functions in the setting interface according to their needs.



1. Screen lock settings

On this page, you can select the unlocking method of screen lock. Currently, it is sliding to unlock, and there are also patterns, pin codes, and password unlocking, as shown in the following figure.



2. Network&Internet



Wi-Fi

Search Wi-Fi AP, input password can be connected.

Mobile network/sim card setting: used for cellular network;

Hotspot & tethering: device work as wifi ap;

More network option can be checked on Advanced.





Wi-Fi switch

Wif iusername


3. Connected devices: Bluetooth setting

Search this interface for Bluetooth pairing, remove or cancel paired Bluetooth devices. as the blew picture




4. Apps & notifications

View installed APP storage space size, traffic usage, stop Prompt.




5. Battery

On this page, you can check battery power usage, open power saving mode and make some battery settings, as shown in the following figure.




6. Display

On this page, you can set Brightness adjustment, Night light mode, wallpaper, sleep time, interactive screen saver, font size, screen rotation switch, etc.




7. Sound

Set media volume, alarm volume, notify volume size (can also use physical keys to the corresponding interface directly to adjust, do not disturb settings) notification ringtone settings and other operations.




8. Storage

View system memory usage, install and uninstall SD cards.




9. Security & location

set screen locking mode with some encryption settings, can manage unknown sources of application installation settings, etc.




10. Accounts




11. Accessibility

Click with accessibility, for quick settings of personal operation habits, such as: Caption, magnification gesture, front size, display size, power button ends call, auto-rotate screen, speak password, color inversion, color correction.,





12. System




1) About tablet


view status information, device models, Android version / Android patch level, base band version (mobile network module model), kernel version, software version number, etc.



2) Languages&input




3) Gestures




4) Date&time


Set the time and time zone and time format for 24 hours or 12 hours, or turn on automatic confirmation, which synchronizes automatically when the device is connected to the network.




5) Backup



6) Reset options



7) Multiple users



Support

You have any technical questions?

If you have problems or questions, please contact us by e-mail:

support@pokini.de

V1.0 / 06-2021

EXTRA Computer GmbH
Brühlstr. 12
89537 Giengen-Sachsenhausen
Deutschland / Germany

all rights reserved

www.pokini.de